




Operating Instructions

Rotary Lobe Pump

IQ112

ENGINEERED TO WORK



Original operating instructions

Issuer

Hugo Vogelsang Maschinenbau GmbH
Holthöge 10-14
49632 Essen/Oldb.

Phone: +49 54 34 83 0
Fax: +49 54 34 83 10

vogelsang-gmbh.com
info@vogelsang-gmbh.com

In the absence of express, written authorisation from the issuer, the reproduction or partial reproduction of this document in any form is prohibited.

We reserve the right to make technical modifications to the diagrams and information presented in this document in the event that such modifications become necessary for the enhancement of the machine.

© 2016 Hugo Vogelsang Maschinenbau GmbH

Registered trademarks of Vogelsang

Vogelsang, RotaCut, PreMix, HiFlo, ACC, CFC, BioCrack, XTill, EnergyJet, BioCut, CC series, PreMix, ProTerra and VarioCrop are registered trademarks of Hugo Vogelsang Maschinenbau GmbH.

The registered trademarks are not always designated with an ® symbol in this document.

Dear customer,

in every one of our products, you will see the entirety of our competence and our power of innovation at work. Each product is developed and built so that you can work more successfully.

We call it quite simply: ENGINEERED TO WORK

If you want to know more about our company or put forward requests or suggestions, a wealth of information can be found at www.vogelsang.info

Issuer	2
Table of contents	3
1 User information	6
1.1 Using the operating instructions	6
1.2 Presentation convention	6
1.3 Explanation of symbols	7
1.4 Machine versions described here	8
2 EC declaration	9
3 Specifications	10
3.1 Material description for rotary lobes	11
3.2 Name plate	12
4 Safety	13
4.1 Operator's responsibilities	13
4.2 Personnel qualification	14
4.2.1 Qualifications	14
4.2.2 Fields of activity	14
4.3 Intended use	15
4.4 General safety notes	15
4.5 Safety devices	16
4.5.1 EMERGENCY STOP shutdown (main switch)	16
4.5.2 Maintenance and repair switch	16
4.6 Warning and safety stickers on the machine	17
5 Transport, storage	18
5.1 Transport	18
5.2 Storage	19
6 Assembly	20
6.1 Installation in pipes	20
6.2 Pipes	21
6.3 Direction of flow	23
6.3.1 Pump with motor drive	23
6.3.2 Pump systems	23
6.4 Pump connection	24
6.5 Base, support surface for machine	25
6.5.1 Machine without base	25
6.5.2 Machine and motor on base C (with coupling)	25
6.5.3 Coupling orientation	26
6.5.4 Machine and motor on base B (belt drive)	27
6.5.5 Machine on hand cart	27
6.6 Drive	28
6.6.1 Electric drive	29
6.6.2 Hydraulic drive	30
6.6.3 Combustion engine drive	31
6.7 System control	32
7 Start-up	33

8	Maintenance.....	35
8.1	Buffer chamber.....	35
8.1.1	Pressurisable buffer fluid tank	36
8.1.2	Buffer fluid – type	39
8.1.3	Buffer fluid – amount.....	39
8.1.4	Buffer fluid – inspection and change	39
8.2	Draining and cleaning the buffer chamber	40
8.3	"Dry buffer chamber" sealing system	41
8.4	Gearbox.....	42
8.4.1	Gear oil - grade	42
8.4.2	Gear oil - quantity	42
8.4.3	Gearbox oil – inspection and change	42
8.5	Oils	43
9	Repair	47
9.1	Conversion and spare parts	47
9.2	Opening the IQ cover	48
9.3	Rotary lobe change	49
9.4	Change of wear plates	51
9.5	Change of cartridge mechanical seal.....	52
9.6	Closing the IQ cover.....	54
10	Troubleshooting	55
10.1	Troubleshooting	55
10.2	Help.....	55
11	Putting out of operation and disposal.....	57
12	Maintenance plan	59
12.1	Maintenance instructions	59
12.2	Maintenance intervals	59
12.3	Additional maintenance intervals for pumps with belt drive.....	60
13	Service plan	61

Table of figures

Fig. 1: Name plate	12
Fig. 2: Positions of the warning and safety labels	17
Fig. 3: Transport aids.....	18
Fig. 4: Installation variants	20
Fig. 5: Long suction lines	22
Fig. 6: Drive units.....	23
Fig. 7: Sight glass (A)	23
Fig. 8: QuickFlange assembly	24
Fig. 9: Orientation procedure.....	26
Fig. 10: Vent screw on the gearbox (removing the seal).....	29
Fig. 11: Buffer fluid tank.....	36
Fig. 12: Filling/draining the buffer chamber	37
Fig. 13: Installation example - dry buffer chamber	41
Fig. 14: Gear oil change	42
Fig. 15: Opening/closing the IQ cover	48
Fig. 16: Rotary lobe change.....	50
Fig. 17: Installation position of the curved wear plate	51
Fig. 18: Cartridge mechanical seal on the gearbox.....	53

Relevant documents

- Dimension sheet / drawing
- Characteristic line
- EC declaration of conformity

Optional:

- Technical information on drive system
- Technical information on safety devices

Please read and adhere to the information and instructions in the relevant documents.

1 User information

1.1 Using the operating instructions

These instructions contain information concerning operating elements, handling, start-up and maintenance and repair work, as well as the relevant specifications.

The operating instructions are a component of the machine.

IMPORTANT READ CAREFULLY BEFORE USE

Read the operating instructions thoroughly. All of the points presented in these instructions must be understood and observed by those persons responsible for the installation, operation, maintenance and repair of the machine.



Vogelsang does not accept any liability for damage resulting from failure to comply with these operating instructions.

KEEP FOR FUTURE REFERENCE

Please keep the manual ready at hand to ensure easy access to the necessary information at all times.

Additional copies of the manual are available upon request. ☎️✉️

1.2 Presentation convention

Presentation	Meaning
•	Listing
–	Sublisting
1. 2.	Carry out these actions in the described sequence
→ Fig. "Caption"	Reference to a figure for additional information
→ Chapter "Chapter heading"	Reference to a chapter for additional information
→ Table "Table caption"	Reference to a table for additional information
 "Relevant document"	Reference to a document for additional information
 Technical support	Contact our technical support

1.3 Explanation of symbols

The following symbols and signal words are used in this manual:

- 1 If personal protective equipment is needed to work with and on the machine, that is indicated by the following symbols:



Indicates that protective gloves must be worn for subsequent tasks.



Indicates that protective goggles must be worn for subsequent tasks.



Indicates that safety shoes must be worn for subsequent tasks.

- 2 This symbol draws attention to the use of tools:



Tools, mounting devices and resources required for the following work tasks.

- 3 General notices and information about environmental protection are marked by these symbols:



NOTE

Refers to further information and useful notes.



ENVIRONMENTAL PROTECTION

Refers to measures to be observed to prevent damage to the environment.

4 Safety notes are introduced by these symbols and words:



CAUTION

Refers to a dangerous situation in which failure to comply with the safety note could result in light injuries.



WARNING

Refers to a dangerous situation in which failure to comply with the safety note could result in death or serious injuries.



DANGER

Refers to an (extremely) dangerous situation in which failure to comply with the safety note will result in death or serious injuries.



RISK OF ELECTRIC SHOCK

Touching live parts leads to dangerous electrocution.
This can result in electric shock, burns or death.



ATTENTION

Refers to possible damage to machinery or property as a result of failure to comply with this note.

1.4 Machine versions described here

In → **Chapter** "Installation", the following optional machine versions are described:

Machine version	Chapter reference
• With or without pump connectors	→ Chapter "Pump connector"
• On a base or without a base	→ Chapter "Base, support surface for machine"
• With the following drive options:	→ Chapter "Drive"
– Electric drive	
– Hydraulic drive	
– Combustion engine drive	
• With or without system control	→ Chapter "System control"

The machines listed in these operating instructions are subject to the Machinery Directive (2006/42/EC), see sample printout in → **Chapter** "EC declaration".

2 EC declaration

(sample printout)

EC Declaration of conformity

According to Machinery Directive 2006/42/EC; annex II A

Manufacturer: Hugo Vogelsang
Maschinenbau GmbH
Holthöge 10-14
D-49632 Essen/Oldb.

We hereby declare that the machine described below meets the basic health and safety requirements of the Machinery Directive 2006/42/EC in its design and construction and in the version marketed by us. If a change is made to the machine without our agreement, this declaration loses its validity.

Product: Rotary lobe pump

Applied harmonised standards:

DIN EN ISO 12100:2010
DIN EN 1037:1995+A1:2008
DIN EN 349:1993+A1:2008
DIN EN ISO 13857:2008
DIN EN 809:2012

Applied national standards and technical specifications:

DIN EN 82079-1:2012
DIN 4844-1:2012
DIN 4844-2:2012
DIN ISO 3864-1:2012

The person authorized to compile the technical documentation is:
Hugo Vogelsang Maschinenbau GmbH; Holthöge 10-14; 49632 Essen (Oldb.), Germany

49632 Essen, 2015-09-30



Harald Vogelsang (Managing Director)

3 Specifications

IQ112 series	Max. speed: 900 min ⁻¹			Max. differential pressure**	Theoretical operating torque***
	Displacement	Theoretical volume flow*			
Size	[l]	[l/min]	[m³/h]	[bar]	[Nm]
81	1.02	918	55.08	7	165
114	1.44	1298	77.88	5	160

* All values refer to the theoretical volume flow. The actual volume flow is lower; it depends on the operating conditions in each case.

** Valid only for short operation times. For continuous operation, please contact our service department.



The service life of the lobes is reduced by high temperatures, especially in combination with high pressure. Observe the material-specific differential pressure limits → **Notice**.

*** Theoretical operating torque with max. differential pressure and water, designed for NBR elastomers.



ATTENTION

Material-specific differential pressure limits

Rotary lobe made of FPM: max. 6 bar



Maximum free passage: Ø 33 mm



ATTENTION

When using the pump for a **highly viscous medium**, the pump speed must be reduced according to the material's viscosity, to prevent the intake flow from breaking off on the suction side (cavitation protection).

Weights and dimensions

For the machine's weight and dimension specifications, see  "Dimension sheet"

3.1 Material description for rotary lobes

Marking on the rotary lobe	Material	Elastomer-based	Resistant up to	Pump medium	Characteristics
NBR	NBR	Nitrile butadiene rubber	80 °C *	Sewage sludge, petrol, oil, grease, diesel oil, spindle oil	Oil-resistant
NBR	NBR, white	Nitrile butadiene rubber	80 °C *	Oil, butter, linseed and olive oil, lard	Food grade
SBR	SBR	Styrene butadiene rubber	60 °C	Liquid manure	Wear-resistant
SL	EPDM-SL (EPDM-Sewage-Line)	Ethylene propylene diene M-class rubber	80 °C *	Water, liquid manure, sewage sludge, biogas substrate	Not oil and grease resistant, water resistant, steam resistant
AL	EPDM-AL (EPDM-Aqua-Line)	Ethylene propylene diene M-class rubber	80 °C *	Drinking water	Drinking water approved **, not oil or grease-resistant, water-resistant, steam-resistant
EPDM	EPDM, white	Ethylene propylene diene M-class rubber	80 °C *	Water, mash, slightly acidic products	Food grade
PU	PU (Werobust)	Polyurethane vulcanised	50 °C	Abrasive medium	Wear-resistant
PUR	PUR	Polyurethane cast	80 °C	Abrasive medium	Highly wear-resistant
CSM	CSM (Hypalon)	Chloro-sulfonyl polyethylene rubber	80 °C *	Petrol, oil, acids, alkali solutions	Wear-resistant, acid-resistant and alkali-resistant
FPM	FPM	Fluorocarbon gum	80 °C *	Solvents, salt water, oil, petrol, acids	Acid-resistant and alkali-resistant
	Steel lobes (pure material)	1.4571	150 °C 200 °C*	Pure medium Chemistry	High temperatures, high chemical resistance
	Steel rotary lobes (pure material)	C45 nitrided	150 °C 200 °C*	Pure medium petrochemical	High temperatures, chemical resistance

Table: Material description

* consult Vogelsang in the event of the combination of "high differential pressure and high temperatures" ☎️✉️

** drinking water approvals: KTW, DVGW-Arbeitsblatt, W 270, WRAS, BELAQUA



Please consult us ☎️✉️

- If you require combinations with high differential pressure and high temperatures – (see * in → **Table** "Material description").
- With solid material lobes with media containing foreign matter
- If you should discover discrepancies or if precise specifications have not been provided for the medium



ATTENTION

Risk of premature wear on rotary lobes made of FPM in the event of excess pump pressure!

The material 'FPM' for rotary lobes is usable only up to max. 6 bar differential pressure.

Please see → **Chapter** "Specifications".

3.2 Name plate




Fig. 1: Name plate

4 Safety

This section gives you an overview of important safety aspects needed to ensure optimum protection of personnel and to ensure safe and trouble-free operation.

Failure to comply with the instructions and safety information specified in this manual may result in serious hazards.

In the event of any abnormalities and/or signs relating to the safety of the product supplied by Vogelsang, please contact us without delay via:

produktsicherheit@vogelsang-gmbh.com

4.1 Operator's responsibilities

The machine is used commercially. The operator of the machine is therefore subject to the statutory occupational safety regulations.

In addition to the safety information provided in this manual, the relevant safety, accident prevention and environmental protection requirements for the area in which the machine is used must be complied with.

This includes the following, in particular:

- The operator shall ensure that all persons who handle the machine have read and understood this manual. If necessary, the operator shall train personnel and inform them of possible hazards. To improve tracking, we recommend creating a training log.
- The operator shall clearly regulate and define responsibilities for transport, installation, start-up, operation, maintenance, repair, cleaning, troubleshooting, shutdown and disposal.
- The operator shall instruct personnel to always wear the necessary protective equipment and shall monitor usage.

The operator is responsible for ensuring that the machine is always in perfect technical condition.

The following therefore applies:

- The operator shall ensure that maintenance intervals described in this manual are complied with and are documented in the service plan.
- The operator shall have all safety devices checked at regular intervals to ensure that they are fully functioning and complete.

4.2 Personnel qualification



WARNING

Risk of injury due to insufficient qualification!

Handling the machine improperly can result in serious injuries and property damage.

For this reason, all activities must be performed by qualified technical personnel only.

Only persons who can be expected to perform their work reliably are permitted as personnel. Persons whose ability to respond is impaired, for example due to drugs, alcohol or medication, are not approved.

4.2.1 Qualifications

The following qualifications are required for different fields of activity:

Instructed person

Has been instructed by the operator to perform the tasks for which the instructed person is responsible and has been informed of possible hazards in the event of improper behaviour.

Qualified technical personnel

Is able, due to his or her specialist training, skills, experience and knowledge of the relevant provisions, to perform the work for which he or she is responsible, and is able to identify and avoid possible hazards independently.

Qualified electrician

Is able, due to his or her specialist training, skills, experience and knowledge of the relevant standards and provisions, to perform work on electrical systems, and is able to identify and avoid possible hazards independently.

4.2.2 Fields of activity

- The activities described in this manual may be performed by instructed persons unless explicit mention is made of a special qualification that is necessary.
- If activities may only be performed by qualified technical personnel, this fact will be clearly stated in this manual. Safety devices may only be connected and checked by qualified technical personnel.
- Electrical work and work on the electrical system may only be performed by qualified electricians.

Vogelsang must always be consulted prior to any system-specific activities that are not described in this manual. ☎️✉️

Training in the activities described in this manual may be provided by Vogelsang on request. ☎️✉️

4.3 Intended use

The Vogelsang rotary lobe pump (hereinafter "pump" or "machine") is a self-priming positive displacement pump for pumping fluids ranging from water-like to highly viscous (hereinafter "medium").

The medium can be chemically neutral, acidic or alkaline. It can be loaded with solid particles and/or gas. The maximum free passage specified in → **Chapter** "Specifications" must not be exceeded.

The pump is designed to pump the medium specified by the customer.

For a different medium, or if the pump was not designed for a specific application, the materials of the wetted pump components must be checked for suitability. In some cases the pump must be reconfigured.

The pumps described in these operating instructions are not intended for use in potentially explosive atmospheres.

Any other use is contrary to the intended use. Vogelsang is not liable for any damage resulting from such incorrect use.

4.4 General safety notes



WARNING

Risk of injury (catching, crushing, collision) due to rotating rotary lobes if the machine starts up unexpectedly!

Before starting maintenance and repair work (opening covers, disassembling connectors) and before troubleshooting, switch the machine off and secure it against being switched on again.



WARNING

Risk of injury from medium escaping under high pressure!

If the maximum differential pressure is exceeded, machine parts may burst and medium may spray out.

- The maximum differential pressure must not be exceeded → **Chap.** "Specifications".
- Observe and implement the recommendations in → **Chap.** "Installation in pipes".
- Protect the machine or system against overpressure. For example, the following monitoring devices can be used:
 - A current limiter on the motor
 - A pressure relief valve
 - Cut-off with a pressure control switch
 - An overload coupling



WARNING

Skin and eye irritation caused by contact with hazardous working materials or media!

All work on the machine can lead to contact with working materials or media.



- Personnel must wear suitable protective clothing.
- The operator must inform his or her staff about any potentially hazardous substances in working materials or media.



CAUTION

Risk of burning due to exposed host surfaces!

If the medium temperature is greater than 60 °C or the pump experiences dry running, the pump housing, the connectors or the pipes can become very hot.

At high speeds or high differential pressure, the gearbox housing can also become very hot.

- Avoid (accidental) contact with hot surfaces.
- Avoid dry running of the pump, e.g. by means of dry running protection via
 - Temperature monitor
 - Level measurement
 - Flow measurement



ATTENTION

Risk of frost!

To protect the pump against damage caused by frozen medium, drain it when there is a risk of frost.

- Drain the pump by running the pump in either direction (forward or reverse), until all liquid is drained out of the pump. You can use drain cocks in the connectors to do this.
- For complete draining of the pump chamber, remove the IQ cover, → **Chapter** "Opening the IQ cover".
- Before start-up, refill with fluid.

4.5 Safety devices

4.5.1 EMERGENCY STOP shutdown (main switch)

For shutdown in the event of an emergency, an emergency stop must be present and freely accessible at all times.

4.5.2 Maintenance and repair switch



DANGER

Danger if the machine starts up unexpectedly!

To safely exclude the possibility of unexpected machine start-up in accordance with DIN EN 1037, a maintenance and repair switch must be installed in the immediate vicinity of the electric drive so that the electrical power can be safely isolated for maintenance purposes.

The maintenance and repair switch must be secured in its OFF position to prevent it being switched back on again, using a padlock for example.



NOTICE

Switching "OFF" in points 1 and 2 means "all-pole disconnection".



WARNING

Qualified technical personnel must connect and check the safety devices on a regular basis for proper function, especially after performing maintenance and repair work and before start-up.

4.6 Warning and safety stickers on the machine

Warning and safety stickers on the machine

- provide important information for the safe operation of the machine. Observing the stickers is for the safety of persons who work with and on the machine.
- must remain legible, remove any contamination, if required.
- may not be removed and must be replaced immediately if damaged or lost.




Fig. 2: Positions of the warning and safety labels

(example only, the position of the stickers can vary depending on the size)

VAU.133		Before machine start-up, operating instructions must be read!
VAU.138		Buffer or quenching fluid tank
VAU.115		<p>(Only used for pumps with a mechanical seal consisting of the material combination SiSiC-SiSiC)</p> <p>(To avoid adhesion of the mechanical seal faces this pump needs to be rotated (at least one revolution) every two months when not in service!)</p>

5 Transport, storage

5.1 Transport




Fig. 3: Transport aids



WARNING

Risk of crushing or concussion due to falling machine!

The machine may start to sway or topple when it is transported, loaded or set down. To ensure safe transport, note the following:

- Loading and transporting may only be carried out by qualified technical personnel. In other words: The operator of a crane or forklift must be able to show an appropriate authorisation.
- Cranes and hoists as well as forklifts must be designed for the weight of the transport units.
- Standing under raised loads is prohibited. Have people leave the danger area.
- Permissible transport options for the machine: suspended, or bolted onto a Euro-pallet.
- In the case of suspended transport of the machine:
 - Use the lifting eye bolts and/or lifting lugs fitted for hoisting gear and securely fasten the lifting tackle. Use the lifting eye bolts **on the pumps** only for lifting and transporting the pump **without** attachments or system components; for example, motor, connectors or base.
 - If need be, dismount the buffer fluid tank before transport and then assemble it again after transport.

5.2 Storage

Complete pumps, cartridge mechanical seals, individual O-rings and seal components

If not stored and handled properly, the physical characteristics of products made of rubber may change. Possible consequences include excessive hardening, softening, permanent deformation, peeling, cracking or other surface damage.

Long-term storage is possible under the following conditions (longer than 6 months to a maximum of 5 years):

- The storage area should be dry (relative humidity below 65%) and the temperature should be between 5 °C and 30 °C.
- The pump chamber can be sealed with a preservative that is compatible with the material of the rotary lobes and gaskets.
- The products should be protected against light, especially direct sunlight and strong artificial light with a high ultraviolet component.

After a storage period of five years or more and before start-up we recommend:

- Checking and renewing (if necessary) all wetted gaskets and rotary lobes.
- Changing the gear oil and the buffer fluid.

For pumps with a mechanical seal that has SiC-SiC mating materials, the shaft must be turned (at least one revolution) at least every two months so that the sealing surfaces of the mechanical seal rings do not stick together.

6 Assembly

6.1 Installation in pipes

- The pump may be installed either upright or at 45°. If it is installed at 45°, the buffer chamber and gear box drain holes should face downwards.
- When installing the pump, ensure that there is easy access for maintenance work. If the screw plugs for draining the gear oil and buffer fluid are not easy to access, discharge hoses may be used (part no. PBT.013 and/or PBT.014).
- Ensure that the pump is installed without tension and that no tension can develop during operation either.




Fig. 4: Installation variants

6.2 Pipes

- Only use the pipe diameters, wall thicknesses and materials recommended by us or by our representatives. The sealing material must be compatible with the medium.
- Position the pressure and suction connections pointing upwards. This will ensure that the fluid remains in the pump after it is switched off.
- Keep the pipe as free as possible from foreign matter (stones, wood residues, etc.) in order to prevent increased wear on rotary lobes and housing.



ATTENTION

Hazard due to closed pipes!

Pumping must not take place against a closed pipe. The pump shaft seals or even the pump housing or the pipe may be damaged or destroyed by the resulting high pressure. A pressure monitoring system is optionally available from us (setting at 10% over the nominal pressure of the pipe) ☎️✉️.



WARNING

Risk of injury from medium escaping under high pressure!

If the maximum pressure is exceeded, → **Chapter** "Specifications", parts may burst and the pumped medium may be expelled under high pressure.

- Follow the recommendations for pipes. Only use high-pressure pipes on the discharge side:
 - **Up to** nominal diameter DN 150 - PN 16 (bar) pipes
 - **Above** nominal diameter 200 - PN 10 (bar) pipes, except when the discharge pressure of the pump unit is ≥ 10 bar

If you are uncertain about anything, please contact us. ☎️✉️

- During downtimes and periods of hot weather, fermentation may occur in closed pipes. The resulting gas can result in a significant pressure increase that can damage the pump or pump unit and cause the injuries mentioned above. Therefore, ensure that no medium is left in the pump.
- Attention – if a connector **with a sight glass** is installed on the suction side:
The pressure must not exceed **max. 2 bar** during reverse pumping → **Fig.** "Flow direction with pump units".



ATTENTION

To protect from high pressure losses and cavitation, heed the advice for laying the suction lines:

- The maximum suction height is 8 m. This is the maximum distance between the lowest and highest points of the suction pipe. Observe NPSH.
- Suction lines whose diameter is too small may restrict the suction capability of the pump. Caution, risk of cavitation!
If the diameter of the suction pipe is too small, the maximum suction height will be reduced by the loss of pressure due to pipe friction. Contact us for a calculation ☎️✉️.
- Suction lines over 30 m must be laid with a slope of at least $2 \times \text{pipe diameter}$ in the direction of flow, ensuring that the pipeline can never run dry → **Fig. "Long suction lines"**.




Fig. 5: Long suction lines

6.3 Direction of flow

The pump is suited for both flow directions.

Please observe the machine and safety technology exceptions in which the flow direction is predefined → Chapter "Pump units".

6.3.1 Pump with motor drive

If you are using motor-driven pumps with one drive shaft, the flow direction is selected by determining the direction of rotation of the drive motor, such as an electric motor or hydraulic motor.




Fig. 6: Drive units

6.3.2 Pump systems

The pressure and suction sides are rigidly defined by the rotation of the pumps. When there are suction difficulties, it is possible to draw in through the discharge side. A reversal of the flow direction is not possible if the pipelines are protected by automatic check valves.



WARNING

Risk of injury from medium escaping under high pressure!

If a connector has a **sight glass**, the sight glass may burst if the pressure is too high.

A connector with a sight glass must be installed **on the suction side**. The pressure may not exceed **max. 2 bar** during reverse pumping.




Fig. 7: Sight glass (A)

6.4 Pump connection



ATTENTION

Risk of breakage due to connectors under tension!

Flange connections can exert excessive forces on the machine.

The connectors must be mounted stressless. In other words, the connectors have to be precisely one in front of the other, even when they are not screwed into place.

QuickFlange assembly

1. Insert the O-ring in the correct position in the gearbox housing
2. Assemble the QuickFlange connector with QuickFlange brackets and screws.
3. Screw in and tighten the QuickFlange brackets and screws so that they are diagonally opposite each other.



Tightening torque

M 10 hexagon head bolt (8.8, steel): 50 Nm

M 10 hexagon head bolt (A2, stainless steel): 40 Nm




Fig. 8: QuickFlange assembly

6.5 Base, support surface for machine

6.5.1 Machine without base



WARNING

Risk of crushing or concussion due to falling machine caused by insufficient stability!

- The machine must be securely fastened to the supporting surface. The machine must never be held in position by the connected pipe as this could result in the couplings breaking or failing.
- Retighten all machine fastening screws and nuts after 20 operating hours and then every 2000 operating hours (at least once a year).

6.5.2 Machine and motor on base C (with coupling)



CAUTION

Impairment of communication and discomfort due to machine vibration!

A tensioned base or insufficient fastening of the machine and motor to the base can lead to machine vibrations and discomfort.

- Install the base in a stressless manner on the support surface.
- Retighten all screws and nuts for fastening the motor and the machine to the base after 20 operating hours and then every 2000 operating hours (at least once a year).

After fastening the machine to the base and the base to the ground on which the machine is standing, the coupling orientation must be checked and realigned, if necessary.

In addition, also read and observe the following:  "Coupling manufacturer's operating instructions"



WARNING

Injuries caused by friction, catching, abrasion from the exposed rotating drive shaft or coupling!

If the machine starts up unexpectedly during adjustment or repair work on the coupling or the dismantled coupling guard, this can result in accidental contact with the exposed rotating drive shaft or coupling.

Before performing adjustments or repair work on the coupling, switch the machine off and secure it against being switched on again.

6.5.3 Coupling orientation



ATTENTION

Vibration and wear due to incorrectly oriented coupling!

If completely assembled at the Vogelsang plant, the alignment between the machine and the motor has been optimally adjusted.

In the case of a drive provided by the operator, the tolerance specifications of the manufacturer of the coupling must be complied with.

- To protect the machine against damage caused by vibrations, check the orientation of the coupling before start-up and then every 2000 operating hours (at least once a year) and correct it, as necessary → Fig. "Orientation procedure".
- If alignment errors are determined or after any blockage e.g. by foreign matter, check the function of all parts of the drive line and readjust it, if necessary.
- In the event of any unusual running noises or vibrations, check the coupling immediately, regardless of the maintenance intervals.




Fig. 9: Orientation procedure

Coupling guard



WARNING

Injuries caused by friction, catching, abrasion from the exposed rotating coupling!

During start-up and operation of the machine, the rotating coupling may be touched accidentally.

- The coupling must be completely covered by a coupling guard.
- The machine may only be started up again after maintenance, repairs or troubleshooting once all the protective equipment has been re-installed.
- Check the fixed coupling of the coupling guard after the first 20 operating hours and then every 2000 operating hours (at least once a year).

6.5.4 Machine and motor on base B (belt drive)



For this type of construction, please request the document “Technical information TINF.PU.020.xx, accompanying sheet for belt drives”.

For machines with belt drive check the belt tension acc. to the accompanying sheet → **Chap.** “Maintenance plan”:

- At start-up
- Before and after long periods of shutdown
- After the first 10 operating hours
- Every 2000 operating hours, once per year minimum

6.5.5 Machine on hand cart



WARNING

Risk of crushing or concussion due to falling machine caused by insufficient stability!

Secure the hand cart against toppling or rolling during standstill and when the pump is in operation.

6.6 Drive

The technical specifications for the drive system to be installed are determined by the machine's specifications → **Chapter** "Specifications".

In addition, also read and note the following:  "Technical information for the drive system to be installed".



WARNING

Injuries caused by friction, catching, grazing from the exposed rotating drive shaft/coupling!

If the machine starts up unexpectedly during assembly or repair work, this can result in accidental contact with the exposed rotating drive shaft/coupling.

- The coupling area must be protected by a screwed cover.
- The machine may only be started up again after maintenance, repairs or trouble-shooting once all the protective equipment has been re-installed.
- Before starting assembly and repair work on the coupling, switch the machine off and secure it against being switched on again.

6.6.1 Electric drive

Connection to the energy supply may only be established by qualified technical personnel **following** installation in the pipe.



RISK OF ELECTRIC SHOCK

Touching live parts leads to dangerous electrocution.
This can result in electric shock, burns or death.



RISK OF ELECTRIC SHOCK

The equipotential bonding shall be executed in accordance with standard EN 60204-1. In other words, all metallic parts of the machine or plant must be connected electroconductively to each other or to the signal ground.



In addition, also read and note the following: "Technical information for geared motor"

Before connecting the geared motor (electric motor with or without gearbox)

- Check that the power supply is correct for the motor.
- Check that the power feed and fuse protection are adequately dimensioned to allow for multiple rotation direction changes and peak loads within a short period of time.
- Be sure to follow the cable layout diagram on the inside of the motor terminal box cover.
- Note that the PTC resistor of the geared motor must be connected to the terminals provided on the pump control, to a PTC control unit or to a variable frequency drive with a PTC input (each available as an option).
- Install a maintenance switch in close proximity to the machine (recommendation).

Before start-up or long-term storage

The seal on the vent screw (if present) must be removed in order to prevent overpressure build-up in the gearbox and thus leakage.




Fig. 10: Vent screw on the gearbox (removing the seal)

6.6.2 Hydraulic drive

Connection to the energy supply may only be established by qualified technical personnel **following** installation in the pipe.



WARNING

Risk of infection from hydraulic oil!

Leakages can occur due to seal faults.



- Personnel must wear suitable protective clothing.
- The connection to the power supply must be established by qualified technical personnel.

In the event of injuries with hydraulic oil, consult a doctor immediately!

In addition, also read and observe the following:  "Technical information for hydraulic motor"

Hydraulic hose lines

- Before connecting hydraulic hoses, read and follow the manufacturer's specifications for hydraulic motors.
- Observe the permissible hydraulic pressure and the permissible delivery rate.
- Connect the overflow oil line in accordance with the manufacturer's instructions.
- Replace hydraulic hose lines that show signs of damage or ageing. Only use genuine Vogelsang hydraulic hose lines.
- The date of manufacture of the hydraulic hose line is displayed on the pressing component of the connector. The period of usage for the hydraulic hose line should not exceed 6 years (although 5 years is recommended), including a possible storage period of no more than 2 years.

Installing two hydraulic motors

When two hydraulic motors are installed, they are operated parallel and the torques of both motors are added.

Control unit

In the event of high hydraulic motor speeds, never suddenly set the control unit to "lock position" in order to avoid pressure peaks. Whenever possible, switch from "operation" to "floating position".

6.6.3 Combustion engine drive

In addition, also read and note the following:  "Technical information for combustion engine"

Before start-up

- Fill the tank with fuel. The fuel must meet the specifications in the operating instructions.
- Fill up with sufficient operating oils. The oil grade must meet the specifications in the operating instructions.



DANGER

In enclosed or poorly ventilated spaces, poisonous engine exhaust gases can lead to a loss of consciousness and death!

- Never operate the engine in enclosed or poorly ventilated spaces.
- Do not breathe in exhaust gases.



DANGER

Fire hazard due to fuel!

Leaking or spilled fuel can ignite on hot motor parts and cause serious burns.

- Only refuel when the engine is switched off.
- Never refuel in the vicinity of open flames or ignitable sparks.
- Do not smoke.
- Do not spill fuel.



WARNING

Risk of burning due to exposed hot surfaces!

Parts of the exhaust system and the surface of the engine become hot during operation and must not be touched until they cool down again once the engine has been switched off.

6.7 System control



Controls

We recommend our control system, which is specially designed for use with the pump in order to provide optimum service life for the pump. All connections necessary for connecting the pump to a control system are available.

If a new control is made by a switching system manufacturer, the new manufacturer must make the network connections in AC4.

Please contact us with regards to the correct programming of the control system ☎️✉️.



Automatic mode requires monitoring equipment

Machines that are operated in automatic mode must be equipped with a temperature and pressure monitoring system. This monitoring equipment can be obtained from us as an option.

Variable frequency drive operation

In general, rotary lobe pumps can be used in variable frequency drive operation.

Advantages:

- Adaptation to operating conditions (viscosity, delivery rate, $NPSH_{avail.}$)
- Wear compensation
- Speed-proportional delivery rate (see characteristic line)
- Increasing acceleration and deceleration times
 - Reduces pressure peaks
 - Reduces the risk of pipe vibrations

A variable frequency drive with a linear torque characteristic line is to be used.
The starting torque / nominal torque ratio must be > 1.3 .

7 Start-up



Personnel for start-up and operation

We recommend starting up the machine in the presence of persons who are responsible for further operation of the machine.



WARNING

Risk of injury, catching by rotating rotary lobes!

The pump may only start-up if the inlet and outlet pipes are connected so that access to the rotating rotary lobes in the pumping chamber is not possible.

Check list before start-up

Pump connector

- ☐ Are the inlet and outlet lines connected?
- ☐ Are the drain cocks closed, and is the pump filled with fluid?

Base, coupling

- ☐ Is the coupling, if present, correctly oriented (see documents provided by the coupling manufacturer)?

Drive

- ☐ Is the belt tension, if applicable, OK?



See "Technical Information TINF.PU.020.xx, accompanying sheet for belt drives".

- ☐ Is the motor connected correctly to the power supply, if applicable (→ documents provided by the motor manufacturer)?

- ☐ Star or delta connection, voltage, frequency (see name plate and inside of terminal box)?
- ☐ Motor protection ensured, e.g. by a circuit breaker?
 - A short switching time should be set for star-delta starting (if present).
 - A short start ramp should be set for the soft starter, if present.
- ☐ Is the variable frequency drive/soft starter, if present, designed and configured correctly?
 - Units should be suitable for heavy starting

- ☐ Is the motor connected correctly to the hydraulic lines, if applicable (→ documents provided by the motor manufacturer)?

Buffer chamber, pump gearbox

- ☐ Are the buffer chamber assemblies installed correctly?
Is the buffer chamber pressure OK (if applicable)? → **Chapter** "Maintenance" – "Buffer chamber"
 - ☐ Is the type of buffer fluid OK?*
 - Is the fluid level in the buffer chamber OK?*
 - ☐ Are the oil grade and oil level in the gearbox of the pump OK?*
- *Requirements met by the pump when delivered*

Flow direction, pipe system

- ☐ Is the flow direction OK? Check the pump's direction of rotation.
- ☐ Is the pipe system tight and free of leakage?
- ☐ Is unobstructed flow guaranteed in the pipe system?
Positive displacement pumps must never be operated in a sealed pipe.

Sensors, safety

- ☐ Have all safety devices been installed and is their proper functioning ensured?
- ☐ Are the safety devices or maintenance switches easy to reach?

Put the pump into operation and check inlet and outlet pressure, speed and capacity.

8 Maintenance



WARNING

Risk of injury (catching, crushing, collision) due to rotating rotary lobes if the machine starts up unexpectedly!

Before starting maintenance and repair work (opening covers, disassembling connectors) and before troubleshooting, switch the machine off and secure it against being switched on again.



WARNING

Risk of injury from working materials escaping under high pressure!

When the drain plugs on the gearbox and buffer chamber are loosened or the buffer fluid tank cover is opened, working materials can spray out under high pressure.



- Personnel must wear suitable protective clothing.

Before carrying out maintenance and repair work, release the buffer chamber pressure.

- To protect against fluids spraying out, carefully and slowly open the buffer chamber and the gearbox. Cover the valves or screws to be removed with a cloth or similar item where appropriate.

8.1 Buffer chamber

In the next chapter, we describe the buffer chamber assembly "pressurisable buffer fluid tank"

This buffer chamber assembly is for improving the monitoring of the pump shaft seal. The fluid level and the set pressure can be monitored.

Electronic buffer chamber monitoring is also possible. Ask us for more information. ☎️✉️

If your pump is equipped with a dry buffer chamber, please read the corresponding → **Chapter** "Sealing system" "Dry buffer chamber".

8.1.1 Pressurisable buffer fluid tank

The pressurisable buffer fluid tank (hereafter referred to as "tank") with manual air pump ensures a constant and defined buffer chamber pressure (buffer chamber pressure = tank pressure). The tank provides reliable monitoring of the buffer chamber.

Installing the tank (before pump start-up)

1. Remove the plug from the buffer chamber.
2. Open the tank: undo the upper coupling of the upper housing (hold the union nut firmly in place so that the lower coupling is not detached).
3. Screw the tank directly into the cast body of the buffer chamber. Fill the tank about one quarter full (when delivered, the buffer chamber is already filled).
4. Close the tank and use a manual air pump or a compressed-air supply outlet to set the required tank pressure.

Topping up buffer fluid (maintenance and inspection)

→ Fig. "Buffer fluid tank" and "Filling/draining the buffer chamber"

1. Release the pressure in the buffer chamber via the valve on the tank.
2. Open the tank: undo the upper coupling of the upper housing (hold the union nut firmly in place so that the lower coupling is not detached).
3. Top up the buffer fluid in the tank. The tank must be one quarter full.
4. Close the tank and use a manual air pump or a compressed-air supply outlet to set the required tank pressure.




Fig. 11: Buffer fluid tank




Fig. 12: Filling/draining the buffer chamber

- 1 | Screw plug
- 2 | Buffer fluid tank

- A | Filling
- B | Draining

Tank pressure

The tank pressure should be about 0.5 bar higher than the average pressure in the pump.

Tank pressure = 0.5 bar + (pressure on the suction side + pressure on the discharge side) / 2

Example

A pump primes with 0.4 bar suction and discharges with 2.0 bar overpressure.

Pressure on the suction side: -0.4 bar, pressure on the discharge side: 2.0 bar.

$$\text{Tank pressure} = 0.5 \text{ bar} + \frac{(-0.4 \text{ bar} + 2 \text{ bar})}{2} = 1.3 \text{ bar}$$

In this example, the tank pressure is 1.3 bar.

Regardless of this, the tank pressure should not exceed 5 bar with a single mechanical seal and should not exceed 10 bar with a double mechanical seal.



Rotary lobe change and Cartridge mechanical seal change

Before a rotary lobe and Cartridge mechanical seal change, reduce the **tank pressure** and increase it again after changing.

Trouble indication

Possible indications of trouble in the sealing system after the running-in period:

- Severe contamination of the buffer fluid in the tank
- Buffer fluid escaping (tank is empty)
- Increase in buffer fluid level (tank is full)



Buffer fluid characteristics

- The hydrodynamic lubrication film of a mechanical seal can cause:
 - Slight contamination of the buffer fluid
 - A slight increase or reduction in the buffer fluid level
- A slight increase in the buffer fluid level is also possible due to thermal expansion during pump operation.

8.1.2 Buffer fluid – type

For optimum functioning of the mechanical seal, we recommend the oil grades listed in → **Chapter "Oils"**. Please check your order confirmation to see whether the buffer chamber of your machine is filled with an oil that deviates from this chapter.

Only use the oil specified on your order confirmation.



ATTENTION

To prevent premature wear of the seal, mineral oils or greases must not be used with EPDM O-rings. Use glycol as an alternative.

To prevent contamination of the pump medium, **no fluid** must be filled into the buffer chamber of pumps with the "dry buffer chamber" sealing system.

8.1.3 Buffer fluid – amount

1.1 litre

8.1.4 Buffer fluid – inspection and change

Buffer fluid

- Check:
 - After the first 20 operating hours
 - Every 200 operating hours
- Change:
 - Every 2000 operating hours
 - In the event of severe contamination

Electronic buffer chamber monitoring is possible. Ask us for more information. ☎️✉️

If there is intense leakage, replace the cartridge mechanical seal → **Chapter "Cartridge mechanical seal change"**.

→ **Chapter "Maintenance plan"**



Buffer fluid characteristics

- The hydrodynamic lubrication film of a mechanical seal can cause:
 - Slight contamination of the buffer fluid.
 - Slight increase or decrease in the buffer fluid level.
- A slight increase in the buffer fluid level is also possible due to thermal expansion during pump operation.



Environmentally friendly disposal

Treat buffer fluids, such as oils and hydraulic fluids, like hazardous waste and dispose of them properly.

8.2 Draining and cleaning the buffer chamber



Draining and cleaning the buffer chamber

- If the cartridge mechanical seal is defective, drain and clean the buffer chamber.
- Before changing a cartridge mechanical seal, drain the buffer chamber, and clean it if it is contaminated severely.

Procedure

→ Chap. "Buffer chamber"

1. Depressurise the buffer chamber.
2. Remove the buffer fluid tank.
3. Undo the lower screw plug (1) → Fig. "Filling/draining the buffer chamber".
4. If there is severe contamination, clean the buffer chamber.
5. Screw the lower screw plug back in (tightening torque: 60 Nm) and install the buffer fluid tank.
If the lower screw plug is not accessible due to the installation position, a drain pipe can be installed at the side on request. ☎️✉️

8.3 "Dry buffer chamber" sealing system

This sealing system is only used if it is essential to prevent buffer chamber fluid from getting into the pump medium. It is used for pumps that pump pure, non-abrasive media, e.g. water.

To prevent contamination of the pump medium, **no fluid** must be filled into the buffer chamber of pumps with the "dry buffer chamber" sealing system.

Medical white oil, part no. BSS.010, can be used as the gear oil.



Notice

White oil, part no. BSS.010: approved only for continuous operation up to 50% of the max. approved differential pressure of the pump → **Chapter "Specifications"**.

Please contact us. ☎️✉️



ATTENTION

To protect against seal damage, dry running of the pump must be avoided on pumps with a dry buffer chamber. Before start-up, remove the plug from the vent screw (5) → **Fig. "Installation example - dry buffer chamber"** and completely fill the pump chamber with fluid.

Combination of mechanical seal rings in this sealing system

Type of construction: block ring

Mating materials: AISI 304/AISI 316 Ti tungsten carbide coated/carbon

Installation

→ **Fig. "Installation example - dry buffer chamber"**

Connect tank (3) with connecting pipe (4) at the bottom of the buffer chamber. The tank must be installed below the buffer chamber in order to collect medium leakage. The fluid level in the tank should come up no further than the bottom edge of the buffer chamber.




Fig. 13: Installation example - dry buffer chamber

Monitoring the buffer chamber

If the tank (3) is filled with leaked fluid (e.g. pump medium, gear oil or condensed water), undo the wing nuts (1), unscrew the tank cover (union nut (2)) and drain the tank. If the tank is filled by more than half within a month, please contact our service department. ☎️✉️

8.4 Gearbox

8.4.1 Gear oil - grade

We recommend the oils listed in → Chapter "Oils".

8.4.2 Gear oil - quantity

1.4 litre

8.4.3 Gearbox oil – inspection and change

→ Fig. "Gearbox oil change"

Check the gearbox oil and top up small quantities up to the seal indicator pipe (C) (only top up when the gearbox is at a standstill): → Fig. "Changing of gearbox oil".

Every 500 operating hours, however at least every 3 months

Change gearbox oil:

- After the first 20 operating hours
- Every 2000 operating hours

The buffer fluid should be changed at the same time as the gearbox oil → Chap. "Buffer chamber".




Fig. 14: Gear oil change

- | | |
|---|---------------------|
| 1 | Screw plug |
| 2 | Magnetic screw plug |

- | | |
|---|----------|
| A | Filling |
| B | Draining |
| C | Checking |



- The screw plug 1 must be at the top; the magnetic screw plug 2 must be at the bottom.
- Tightening torque for mounting the screw plugs → 60 Nm

8.5 Oils

1 Standard Vogelsang oil for pump gearboxes and buffer chamber

Part number	BSS.006	
Description	EP (Extreme Pressure) gear oil	
Trade name (Fuchs)	Titan Gear MP 90	
Characteristics		Test acc. to
SAE class	90 (85W-90)	DIN 51512 or SAE J306c
Kinematic viscosity		DIN 51562
at 40 °C	198 mm ² /s	
at 100 °C	17.3 mm ² /s	
Flash point	215 °C	DIN ISO 2592
Pour point	-18 °C	DIN ISO 3016
Damage loading step	≥ 12	
Water hazard class	Slightly hazardous to waters	

2 Alternative oils for pump gearboxes and buffer chamber

Part number	BSS0021*	
Description	Fully synthetic industrial gear oil based on poly-alpha-olefins	
Trade name (Fuchs)	Renolin Unisyn CLP	
Characteristics		Test acc. to
ISO VG	220	DIN 51519
Kinematic viscosity		DIN EN ISO 3104
at 40 °C	220 mm ² /s	
at 100 °C	26.7 mm ² /s	
Flash point	260 °C	DIN ISO 2592
Pour point	-42 °C	DIN ISO 3016
Damage loading step	≥ 12	
Water hazard class	Slightly hazardous to waters	

* When using BSS0021 oil for the pump gearbox, the maintenance interval for checking and changing the gear oil may be doubled → **Chapter** "Maintenance plan".

Part number	BSS.010**	
Description	Medical white oil: water-white, non-fluorescent, tasteless and odourless mixture of hydrocarbons	
Trade name (Fuchs)	White oil W 530 (PH.EUR.)	
Characteristics		Test acc. to
Kinematic viscosity		DIN 51562
at 20 °C	238 mm ² /s	
at 40 °C	68 mm ² /s	
at 100 °C	8.4 mm ² /s	
Flash point	230 °C	DIN ISO 2592
Pour point	-24 °C	DIN ISO 3016
Ambient temperature	-20°C to +40°C	
Water hazard class	Slightly hazardous to waters	

** Approved only for continuous operation up to 50% of the max. approved differential pressure of the pump → **Chapter** "Specifications". Please contact us. ☎️✉️



Sealing system with mechanical seal ring made of Duronit

If a mechanical seal ring made of Duronit is used in the sealing system, the damage loading step for the buffer chamber oil must be ≥ 12 .

3 Alternative oils for the buffer chamber

Part number	BSS.014	
Description	Mineral oil based hydraulic and lubricating oil	
Trade name (Fuchs)	Renolin B 15	
Characteristics		Test acc. to
ISO VG	46	DIN 51519
Viscosity index	105	DIN ISO 2909
Kinematic viscosity		DIN EN ISO 3104
at 40 °C	46 mm ² /s	
at 100 °C	6.9 mm ² /s	
Flash point	210 °C	DIN ISO 2592
Pour point	-24 °C	DIN ISO 3016
Damage loading step	≥ 12	
Water hazard class	Slightly hazardous to waters	

Part number	BSS.016	
Description	Biodegradable, environmentally friendly, multigrade hydraulic oil based on rape seed oil (as per ISO 15308, type HETG)	
Trade name (Fuchs)	Hydraulic oil 40 N	
Characteristics		Test acc. to
ISO VG	46	DIN 51519
Viscosity index	220	DIN ISO 2909
Kinematic viscosity		DIN 51562-1
at 40 °C	42 mm ² /s	
at 100 °C	9.6 mm ² /s	
Flash point	300 °C	DIN ISO 2592
Pour point	-36 °C	DIN ISO 3016
Water hazard class	Slightly hazardous to waters	

4 Oils for the buffer chamber with electronic buffer chamber monitoring

Part number	BSS.021	
Description	Fully synthetic EP industrial gear oil based on selected polyglycols (PAG)	
Trade name (Fuchs)	Renolin PG 100	
Characteristics		Test acc. to
ISO VG	100	DIN 51519
Kinematic viscosity		DIN EN ISO 3104
at 40 °C	100 mm ² /s	
at 100 °C	19.6 mm ² /s	
Flash point	260 °C	DIN ISO 2592
Pour point	-48 °C	DIN ISO 3016
Damage loading step	≥ 12	

Part number	BSS.017	
Description	Fully synthetic EP industrial gear oil based on selected polyglycols (PAG)	
Trade name (Fuchs)	Renolin PG 46	
Characteristics		Test acc. to
ISO VG	46	DIN 51519
Viscosity index	203	DIN ISO 2909
Kinematic viscosity		DIN 51562
at 40 °C	46 mm ² /s	
Flash point	240 °C	DIN ISO 2592
Damage loading step	≥ 12	
Water hazard class	Slightly hazardous to waters	

9 Repair



WARNING

Risk of injury (catching, crushing, collision) due to rotating rotary lobes if the machine starts up unexpectedly!

Before starting maintenance and repair work (opening covers, disassembling connectors) and before troubleshooting, switch the machine off and secure it against being switched on again.



WARNING

Skin and eye irritation caused by contact with hazardous working materials or media!

All work on the machine can lead to contact with working materials or media.



- Personnel must wear suitable protective clothing.
- The operator must inform his or her staff about any potentially hazardous substances in working materials or media.



ATTENTION

Before installing stainless steel bolts and stainless steel nuts:

Clean threads and contact surfaces. Apply anti-seize paste (part no. BKL.014/BAS.001) evenly and in sufficient quantity to the screw head face and bearing face and to the thread using a brush or filling knife etc. to avoid seizing of stainless steel.



VVA

VVA = All steel and cast parts of the machine coming in contact with the medium are made of stainless steel.

9.1 Conversion and spare parts

Modifications or changes to the machine are only permissible after consultation with Vogelsang.

Only accessory parts approved by Vogelsang or genuine spare parts may be used. The use of other parts invalidates the guarantee for any resulting damage.

9.2 Opening the IQ cover

1. Depressurise the entire pump unit.
2. Shut off the connected pipes if possible.
3. Drain the pump as much as possible. Attention! Any remaining fluid will flow out of the machine when the Q cover is dismounted.
4. Depressurise the buffer chamber if necessary → **Chapter** "Buffer chamber".
5. Remove eight hexagon head bolts (1) on the IQ cover (5).
6. Lever the IQ cover (5) out of the spring pins (12), with the rotary lobes holding the IQ cover.
7. Take off the IQ cover and the O-ring (6).




Fig. 15: Opening/closing the IQ cover

9.3 Rotary lobe change



Lobe puller for pump size 81, 114 PBA.D001.TL.N1



ATTENTION

Risk of premature wear on rotary lobes made of FPM in the event of excess pump pressure!

The material 'FPM' for rotary lobes is usable only up to max. 6 bar differential pressure.

Please see → **Chapter** "Specifications".

→ **Fig.** "Lobe change"

When assembling, replace the **O-rings**, cylinder head bolts and plugs.

1. Open the IQ cover (5) → **Chap.** "Opening the IQ cover".
2. Remove plug (7) and undo the cylinder head bolts (8). Pull off the pressure discs (10) using a suitable bolt (cylinder head bolt) or with the threaded rod of the lobe puller.
Remove the O-rings (9, 12).
3. Pull the lobes (13) from the shafts using a lobe puller. Pull the HiFlo lobes from the upper and lower shaft in pairs.
4. Before installing the new lobes, thoroughly clean the contact surfaces of lobes and seal components!
5. To install the new lobes, follow the same sequence in reverse.



Notice: solid material lobes

When assembling solid material lobes, fit an O-ring (14) on the gearbox side of each lobe. The O-rings shown in the Figure (14) are not present with rubberised lobes (not solid material lobes).

6. When installing the pressure discs and spring washers, make sure that the spring washers (11) are positioned correctly in the pressure discs (10) → **Fig.** "Position of pressure disc and spring washer". Carefully press the pressure discs and spring washers into the lobe groove. Spring washers must not fall into the extracting groove. Tighten the spring washers and pressure discs with the cylinder head bolt. Attention! Do not use an impact screwdriver.



Tightening torque of cylinder head bolt

M 10 cylinder head bolt, 10.9 (steel): **45 Nm**

M 10 cylinder head bolt, A4 (stainless steel): **42 Nm**

7. Install plug (7).
8. Close the IQ cover → **Chap.** "Closing the IQ cover".
9. Adjust the pressure in the buffer chamber if necessary → **Chap.** "Buffer chamber".




Fig. 16: Rotary lobe change

Position of pressure disc and spring washer




Fig. 1: Position of pressure disc and spring washer

- 1 | Pressure disc
- 2 | Spring washer

9.4 Change of wear plates



ATTENTION

The wear plates have a defined curvature. To prevent premature wear by the rotary lobes, the correct installation position of the wear plate must be observed during installation → Fig. "Installation position of the curved wear plates".



Tightening torque

Wear plate screws: **20 Nm**




Fig. 17: Installation position of the curved wear plate

- 1 | Wear plate on the gearbox and on the IQ cover
- 3 | Hexagon head bolt with microencapsulation

9.5 Change of cartridge mechanical seal



Cartridge mechanical seal – installation/disassembly tool: Part no. WKZ0455

→ **Fig.** “Cartridge mechanical seal on the gearbox”

1. Depressurise the buffer chamber if necessary → **Chap.** “Buffer chamber”.
2. Drain and clean the buffer chamber.
3. Drain gear oil.
4. If available, dismount locking screws.
5. Follow the steps specified in → **Chap.** “Lobe change” and “Wear plate change”.
6. Remove the slotted set screws (1) of the cartridge mechanical seal (Fig. a)).
7. Put on installation tool (A) and screw the cylinder head bolts (2) into the extracting boreholes of the cartridge mechanical seal (Fig. b)).
8. Smoothly pull out the cartridge mechanical seal using the three hexagon head bolts (3) of the installation tool (Fig. b)).
9. Before installing the new cartridge mechanical seal, carefully remove the burrs on the keyways and clean the cartridge mechanical seal seat in the housing.
10. Push new cartridge mechanical seal onto the shaft. Carefully oil the outer O-rings on the seal carrier (pos. 4 in Fig. b)) before installation. Attention! Do not use mineral oil or grease for O-rings made of EPDM. Use glycol as an alternative.
11. To install the new cartridge mechanical seal, place the installation tool on the cartridge mechanical seal without bolts.
12. Push lobe (without fitting key) onto the shaft.
13. Insert the pressure disc and the cylinder head bolt.
14. Tighten the lobe until the cartridge mechanical seal is flush with the pump housing.
15. Reinstall any removed locking screws.
16. Remove the lobe again.
17. Push O-ring and support ring onto the shaft.
18. Before installing the lobes, thoroughly clean the contact surfaces of the lobes and gasket!
19. Install lobes, wear plates and IQ cover.
20. Top up buffer fluid.
21. Readjust the pressure in the buffer chamber if necessary → **Chap.** “Buffer chamber”.
22. Top up the gear oil.




Fig. 18: Cartridge mechanical seal on the gearbox

- | | | | |
|---|---------------------|---|--------------------------------|
| 1 | Set screw | 4 | O-ring (seal carrier) |
| 2 | Cylinder head bolt* | A | Installation/disassembly tool* |
| 3 | Hexagon head bolt* | | |

* included in tool with part no. WKZ0455

9.6 Closing the IQ cover

→Fig. "Opening/closing the IQ cover"

1. Thoroughly clean the contact surfaces before installing the IQ cover (5).
2. Place the O-ring (6) in the four flat O-ring grooves (13).
3. Put the IQ cover in place, orient it on the spring pins (12) and secure it.
4. Screw in eight hexagon head bolts and tighten them uniformly. **Attention! Do not tilt the IQ cover while doing this, but press it evenly "by hand"! Make sure the O-ring is seated correctly.**

10 Troubleshooting

10.1 Troubleshooting

Troubleshooting

- No pump delivery
- Pump stops after start
- Intake flow breaks away after start
- Irregular pump delivery
- Capacity too low
- Pump blocked
- Power consumption too high
- Drive belt slips
- Leakage on the pump
- Pressure and level variations in the buffer chamber
- Leakage at the mechanical seal
- Extreme pressure and level changes in the buffer chamber
- With a dry buffer chamber:
buffer chamber tank more than half full
- Pump too hot
- Motor too hot
- Noises & vibrations

Help → Chapter "Help"

A, B, D, E, G, J, R
J, K, M, R, S, V
D, E, G, S, V
D, E, G, J
D, G, J, R, S, T, U
C, F, J, K, M, R, U, V
C, M, R, S, V
F, H, M, R, S
C, R, U
O, U, V, W
P, W
P
Q
A, C, M, N, R, S, U
C, K, L, M, R, S, V
C, D, E, F, G, I, J, K, M, N, R, S

10.2 Help

	Possible cause	Possible remedy	Observe notices and safety notes → Chapter
A	Pump is not priming	Fill the pump with fluid.	
B	Incorrect direction of rotation	Change the pump's direction of rotation.	"Flow direction"
C	Pipe causing pump housing warping	Check the orientation of the pipe to the pump. If necessary, provide a compensator or secure the pipe.	"Installation in pipes"
D	Leakage in the suction pipe	Check the suction-side pipe system for leakage.	
	Gas formation	Vent the suction pipe and pump chamber, top up fluid.	
E	Suction pipe clogged	Check the free flow of the pipe system on the suction side.	
F	Foreign matter in medium	Clean the pump unit. Install strainer in the suction pipe.	
G	NPSH _a too low (medium evaporates during feeding)	Increase the suction pipe diameter, shorten the suction pipe length, simplify suction pipe assembly, reduce the suction height, reduce the speed, adjust the medium temperature.	"Installation in pipes"
H	Belt tension too low	Tighten in accordance with manufacturer's specifications.	"Base, support surface for machine"
I	Coupling not correctly aligned	Check the orientation and align according to manufacturer's specifications if necessary.	
J	Belt drive slips	Tighten in accordance with manufacturer's specifications.	

	Possible cause	Possible remedy	Observe notices and safety notes → Chapter
K	Faulty electrical connection	Check electrical equipment.	"Drive"
	Error in the hydraulic system	Check the hydraulics.	
L	Motor speed too low during variable frequency drive operation	Install external fan, increase motor speed.	"System control": Variable frequency drive operation
M	Stiff running caused by swollen lobe elastomer	Check the medium resistance of the lobe elastomer.	"Specifications": Material description for rotary lobes
	Stiff running caused by accumulation of solid matter in the gaps	Clean pump chamber; increase the gaps → Chapter "Reducing the starting torque"; adjust the drive.	"Repair", "Drive"
N	Oil level in the gearbox is not OK	→ Chapter "Gearbox"	"Maintenance"
O	Operation-related fluctuations in buffer chamber	→ Chapter "Buffer chamber"	"Maintenance"
P	Mechanical seal damage	Change the mechanical seal, → Chapter "Cartridge mechanical seal change"	"Repair"
	Faulty repair of the mechanical seal		
	Buffer fluid tank leaking	Check buffer fluid tank for leaks.	"Maintenance"
Q	Seal leaking	→ Chapter "Dry buffer chamber"	"Maintenance"
R	Differential pressure too high	Reduce differential pressure.	"Specifications"
S	Medium viscosity above the nominal value	Reduce speed. Increase medium temperature.	"Intended use"
T	Medium viscosity below the nominal value	Increase speed, decrease medium temperature, replace wear parts.	"Repair"
	Gaps too large	Reduce gaps → Chapter "Reducing the starting torque" but with the procedure reversed	"Maintenance"
U	Medium temperature above the nominal value	Reduce medium temperature.	"Intended use", "Specifications": Material description for rotary lobes
V	Medium temperature below the nominal value	Increase medium temperature (after consulting Vogelsang).	
W	Mechanical seal elements not in the best position	Pressurise the buffer chamber once with the max. permissible buffer chamber pressure (tank pressure) (single mechanical seal: 5 bar, double mechanical seal: 10 bar). Then restore the design pressure.	"Buffer chamber" "Pressurisable buffer fluid tank"
		Put the buffer chamber into operation in its non-pressurised state (buffer fluid tank closed) and observe the buffer chamber fluid level and pressure.	
		Adjust the tank pressure (buffer chamber pressure) to be higher than its design pressure. Observe max. permissible buffer chamber pressure (tank pressure): Single mechanical seal: 5 bar, double mechanical seal: 10 bar	

11 Putting out of operation and disposal

1. Disconnect pump from the power supply. Observe notices and safety instructions → **Chapter** "Drive".
2. Disconnect pump from the pipe. Observe notices and safety instructions → **Chapter** "Installation in pipes".



WARNING

Risk of injury by crushing or impact!

Pipes under flexural strain can spring back under spring energy.



- Personnel must wear suitable protective clothing.
 - Carefully undo screws.
3. Drain working materials.
 - Drain the gear oil from the pump gearbox. Observe notices and safety instructions → **Chapter** "Gear oil – inspection and change".
 - Drain buffer fluid from the buffer chamber. Observe notices and safety instructions → **Chapter** "Draining and cleaning the buffer chamber".
 4. Drain the pump and remove residual medium. Observe notices and safety instructions when opening the pump cover → **Chapter** "Repair".



Environmentally friendly disposal

Working materials such as oils, hydraulic fluids and dangerous media should be treated as hazardous waste and disposed of properly.

5. Hand over the pump for scrapping. Observe notices and safety instructions → **Chapter** "Transport, storage".

Maintenance and service plan

12 Maintenance plan

12.1 Maintenance instructions



ATTENTION!

Carefully follow the following maintenance instructions and, if applicable, document them in the service plan → Chap. "Service plan".

Safety devices must be checked on a regular basis for proper function, especially after maintenance and repair work and before start-up.

Observe and comply with the **maintenance instructions in the relevant documents** → Chap. "Relevant documents".

Change the buffer fluid **if it is severely contaminated**.

If the machine's **running noise changes** or if vibrations occur → Chap. "Trouble-shooting".

To avoid the adhesion of the mechanical seal rings' sealing surfaces, the shaft on **new pumps with a mechanical seal with SiC-SiC material combination** that are not put into operation immediately needs to be turned (at least one revolution) about every two months.

12.2 Maintenance intervals



ATTENTION!

Carefully observe the following maintenance intervals and document them in the service plan → Chap. "Service plan".

Before start-up

Check pump/motor (coupling) orientation (base C)

After the first 20 operating hours:

- Retighten the bolts and nuts securing the machine (without base)
- Retighten the screws and nuts for fastening the motor and the machine on the base.
- Check fixed coupling of coupling guard (base C)
- Check buffer fluid
- Change gear oil

Every 200 operating hours:

Check buffer fluid

Every 500 operating hours, at least once every three months:

Check gear oil

Every 2000 operating hours, at least once a year:

- Retighten the bolts and nuts securing the machine (without base)
- Retighten the screws and nuts for fastening the motor and the machine on the base.
- Check fixed coupling of coupling guard (base C)
- Check pump/motor (coupling) orientation (base C)
- Change buffer fluid
- Change gear oil

12.3 Additional maintenance intervals for pumps with belt drive

See also “Technical information for belt drives TINF.PU.020.xx”.

Before start-up and after long periods of shutdown:

Check belt tension and belt orientation

After 0.5 to 4 operating hours:

Check belt tension

Every 6 months:

- Check belt tension
- Check belts and pulleys for wear. In the event of clear signs of wear, check the belt orientation.

13 Service plan

The guarantee is valid only if maintenance and service work is performed and documented acc. to → Chap. “Maintenance plan”.

Serial number: _____

Activity as per maintenance plan	Operating hour meter/ Total capacity	Date	Signature

**Hugo Vogelsang Maschinenbau GmbH**

Holthöge 10-14
49632 Essen/Oldb.

Phone: +49 (0) 54 34 83 0
Fax: +49 (0) 54 34 83 10

vogelsang-gmbh.com
info@vogelsang-gmbh.com

ENGINEERED TO WORK

Australien
Vogelsang Pty. Ltd.
vogelsang.com.au

Indien
Vogelsang India Private Limited
vogelsangindia.com

Russland
Vogelsang Russland
vogelsang.ru

Brasilien
Vogelsang Brasil Ltda.
vogelsang.com.br

Irland
Vogelsang Irland
vogelsang.ie

Schweden
Vogelsang Sverige AB
vogelsang.se

China
Vogelsang Mechanical Engineering (Shanghai) Co., Ltd.
vogelsang.com.cn

Italien
Vogelsang Italy Srl
vogelsang-srl.it

Spanien
Vogelsang S.L.
vogelsang.es

Dänemark
Vogelsang A/S
vogelsang-as.dk

Malaysia
Vogelsang Malaysia
vogelsang.info

Südkorea
Vogelsang Korea Co., Ltd.
vogelsang.co.kr

Deutschland - Niederlassung Ost
Vogelsang Lutherstadt Eisleben
vogelsang-gmbh.com

Mexico
Vogelsang De México S.de R.L. de CV
vogelsang.mx

Tschechische Republik
Vogelsang CZ s.r.o.
vogelsang-czech.cz

Finnland
Vogelsang Oy
vogelsang.fi

Österreich
Vogelsang Austria GmbH
vogelsang-austria.at

USA
Vogelsang USA Ltd.
vogelsangusa.com

Frankreich
Vogelsang France S.A.R.L.
vogelsang.fr

Polen
Vogelsang Poland Sp. z o.o.
vogelsang.pl

Großbritannien
Vogelsang Ltd.
vogelsang.co.uk

Rumänien
Vogelsang Romania SRL
vogelsang.ro