






Technical information

Rotary lobe pump

Tool list for the pump series VX186 / QuickMix

Tool denomination	Part number	Figure
Lobe puller		
VX186-92/130Q	PBA.A001.TK	
VX186-184/260Q	PBA.A001.TL	
VX186-260QD	PBA.A001.T1	
VX186-352/368/390Q	PBA.A001.T2	
VX186-520/780QD	PBA.A001.T3	
Lobe puller extension	PBA.A005	
Installation tool for mechanical seal ring support (PRS.A026.N1.T1)	PBA.A010	
Installation tool for mechanical seal (DGL.A013)	PBA.A006.N1	
Installation tool for radial shaft seal ring (DWD.049)	PBA.A011	
Installation tool for shaft (DWD.067)	PBA.A007.N2	

Tool denomination	Part number	Figure
Installation tool for inner ring (NIR.014)	PBA.A012	
Cartridge mechanical seal assembly/disassembly tool (PRS.A026.N1.T1)	PBA.A014.N1	
Assembly tool for bearing seal housing (PGP.A018.T2)	PBA.A015	
Installation tool for floating bearing (NLG.027)	PBA.A013	
Puller for lip seal race		
to 184Q	PBA.A024.T1	
to 390Q / 260QD / 260QDM2	PBA.A024.T2.N1	
to 520QD	PBA.A024.T3	
Housing gauge	PKL.001	
Fixture for QuickMix worm shafts	WKZ0060	