

Technical information








RotaCut®

RotaCut tool list




Series RCQ-20G






Denomination/application	for RC types	Part no.	Figure
Spanner for slotted nut M35 x 1.5	All of this series	WKZ.039	
Assembly tool adaptor from 1/2" to 46 mm A/F		WKZ.055	
Installation tool for mechanical seal		PBA.D006.N1.T2	
Measuring device for adjusting the angle sensor	All of this series	WKZ0381	
Face pin spanner wrench 1/2"	All of this series with ACC (up to year of construction 2003)	WKZ.012	





Series RCQ-26G/RCQ-33G

Denomination/application	for RC types	Part no.	Figure
Complete tool set for mechanical seal change consisting of:	All of this series	WKZ0477	
1 Open-end spanner for assembling the ACC cylinder		GMS0001	
2 Installation tool for mechanical seal		PBA.B006.N1	
3 Assembly tool for radial shaft seal ring		WKZ0476	
4 Torque bracket for assembling/disassembling the drive shaft		WKZ0475	
Measuring device for adjusting the angle sensor	All of this series	WKZ0381	
Tensioning tool for gas spring NFE.030		WKZ.097	
Detaching tool for drive shaft		WKZ.046	
Fitting tool for drive shaft		WKZ.047	
Complete cutting blade assembly	All of this series	WKZ.082	
Blind flange for mounting on the RotaCut pot without having to dismount the cutter head: enables the medium to continue flowing while the cutter head is being repaired, for example.	RCQ-26 Inline	WKZ0485	
	RCQ-33 Inline	WKZ0484	





Series 3000/5000






Denomination/application	for RC types	Part no.	Figure
Open-end spanner for tensioning nut	All of this series	GMS.001	
Open-end spanner for tensioning nut (strong preload GAS.020)		GMS.003	
Tensioning tool for gas spring NFE.030		WKZ.097	




Denomination/application	for RC types	Part no.	Figure
Face pin spanner wrench 1/2"	All of this series with ACC (up to year of construction 2003)	WKZ.012	
Complete cutting blade assembly	All of this series	WKZ.082	
Complete tool set for pulling and fitting the drive shaft, consisting of:	All of this series	WKZ.043	
1 Detaching tool for drive shaft		WKZ.046	
2 Fitting tool for drive shaft		WKZ.047	
3 Ring spanner wrench with PTO shaft profile 35/45		WKZ.048	
Assembly tool for radial shaft seal ring DWD.054	All of this series	WKZ.091	
Installation tool for mechanical seal	All of this series	PBA.D006.N1.T1	

Denomination/application	for RC types	Part no.	Figure
Blind flange for mounting on the RotaCut pot without having to dismount the cutter head: enables the medium to continue flowing while the cutter head is being repaired, for example.	3000 Inline (for orders before CW32/2012)	GRC.380	
	5000 Inline (for orders before CW32/2012)	GRC0295	
	5000 Inline	WKZ0484	
	3000 Inline	WKZ0485	
Assembly tool for attaching the motor	5000	WKZ0244	




Series 5000pro/10000pro






Denomination/application	for RC types	Part no.	Figure
Open-end spanner for tensioning nut	All of this series	GMS.001	
Open-end spanner for tensioning nut (strong preload GAS.020)		GMS.003	
Tensioning tool for gas spring NFE.030		WKZ.097	
Complete cutting blade assembly	All of this series	WKZ.082	

Denomination/application	for RC types	Part no.	Figure
Face pin spanner wrench 1/2"	All of this series with ACC (up to year of construction 2003)	WKZ.012	
Assembly tool for adjusting the cutting screen support/inner gap seal	All of this series	WMS.003	
Complete tool set for pulling and fitting the drive shaft, consisting of:	All of this series	WKZ.043	
1 Detaching tool for drive shaft		WKZ.046	
2 Fitting tool for drive shaft		WKZ.047	
3 Ring spanner wrench with PTO shaft profile 35/45		WKZ.048	
Assembly tool for radial shaft seal ring DWD.023	All of this series	WKZ.090	
Installation tool for mechanical seal	All of this series	PBA.B006.N1	





Denomination/application	for RC types	Part no.	Figure
Blind flange for mounting on the RotaCut pot without having to dismount the cutter head: enables the medium to continue flowing while the cutter head is being repaired, for example.	5000 <i>pro</i> (all steel pots, except for Inline)	GRC.430	
	5000 <i>pro</i> (all stainless steel pots, except for Inline)	WKZ0010	
	10000 <i>pro</i> (all steel pots, except for Inline)	WKZ0112	
	10000 <i>pro</i> (all stainless steel pots, except for Inline)	WKZ0113	
Assembly tool for attaching the motor	All of this series	WKZ0244	

Series 10000 with hydraulic motor






Denomination/application	for RC types	Part no.	Figure
Open-end spanner for tensioning nut	All of this series	GMS.001	
Open-end spanner for tensioning nut (strong preload GAS.020)		GMS.003	
Tensioning tool for gas spring NFE.030		WKZ.097	

Denomination/application	for RC types	Part no.	Figure
Face pin spanner wrench 1/2"	All of this series with ACC (up to year of construction 2003)	WKZ.012	
Complete cutting blade assembly	All of this series	WKZ.082	
Assembly tool for adjusting the cutting screen support/inner gap seal	All of this series	WMS.003	
Complete tool set for pulling and fitting the drive shaft, consisting of:	All of this series	WKZ.043	
1 Detaching tool for drive shaft		WKZ.046	
2 Fitting tool for drive shaft		WKZ.047	
3 Ring spanner wrench with PTO shaft profile 35/45		WKZ.048	
Installation tool for mechanical seal	10000	PBA.006	






Series RCX-48G


Name/application	for RC types	Part no.	Figure
Tool set Assembly/disassembly: Cartridge Cartridge carrier Drive shaft ACC	All of this series	WKZ0378	
Torque bracket for assembling/dismantling the drive shaft		WKZ0312	
Open-end wrench for assembling the ACC cylinder		GMS0001	
Measuring device for adjusting the angle sensor		WKZ0381	

Series RCX-58G

Name/application	for RC types	Part no.	Figure
Cartridge installation/disassembly tool	All of this series	PBA.B020.N1	
Tool set Assembly/disassembly: Cartridge Cartridge carrier Drive shaft ACC		WKZ0156	
Open-end wrench for assembling the ACC cylinder		GMS0001	
Measuring device for adjusting the angle sensor		WKZ0381	
Face pin spanner wrench 1/2"	All of this series with ACC (up to year of construction 2003)	WKZ.012	

Series RCX-58H (12000 with hydraulic motor)

Name/application	for RC types	Part no.	Figure
Detaching tool for drive shaft	All of this series	WKZ.051	
Adjusting tool for limit switch	All of this series with ACC	WKZ.084	
Assembly tool for floating bearing		WKZ.086	
Assembly tool for lip seal DWD.050		WKZ.085	
Face pin spanner wrench 1/2"	All this series with ACC (up to year of construction 2003)	WKZ.012	

Name/application	for RC types	Part no.	Figure
Locking device for locking block	All of this series without ACC	WKZ0077	
Detaching tool for locking block		WKZ0078	